

Chandelier arm assembly instructions

Important reminders for success:

- Professional installation highly recommended. Warranty void if not installed by licensed professional.
- Never allow fixture to hang by electrical wire only during installation.
- Never twist electrical wire during installation.

1. Unscrew finial (A) and remove finial & body bottom (B) from rod (C).
2. Locate arm assembly (E). Thread wires (F) and threaded nipple (G) through hole in cluster body (H).
3. Secure arm to cluster body by putting lock washer (I) then nut (J) onto threaded nipple. Tighten snugly, but do not overtighten.
4. Attach arm wires to central wires (K). Join exposed ends of white wires together, ditto black.
5. Repeat for remaining arms. All arm wires will join to central wire, black to black and white to white. Reattach body bottom and finial.

